

MTI SPARE PARTS LIST FOR 86XX

INDEXER MODULE

PART NUMBER	DESCRIPTION
03215	LEAD SCREW
03225	PULLEY DRIVE CONVEYOR
03231	NUT, LEAD
100-032	CAPACITIVE SENSOR
109-001	CASSETTE SWITCH
112-012	GEAR MOTOR, LEADSCREW
112-019	GEAR MOTOR, CONVEYOR
201-002	BEARING, FLANGED
201-003	BALL BEARINGS
201-004	SEALS
215-043	SHAFT FOR CONVEYOR
99-00303	PULLEY ASS'Y
99-03234T	HARNESS, INDEXER
99-80039C-01	INDEXER INTERFACE PCB
99-80039C-02M	INDEXER INTERFACE PCB FOR BANNER SENSOR
99-80066B	QUAD SENSOR BOARD
99-80068	SPEED CONTORL BOARD
99-AIO-105	O-RING BELT KIT
AIO-0032	BANNER REFLECTIVE SENSOR

SPINDLE MODULE

PART NUMBER	DESCRIPTION
01091	VACUUM FILTER BOWL
109-014	VACUUM SWITCH
112-005	HI SPEED MOTOR
112-038	CARRIAGE MOTOR, 10:1 RATIO, 24VDC
114-006	SOLENOID VALVE, VACUUM
114-007	SOLENOID VALVE, SOLVENT
114-020	SOLENOID VALVE, CENTERING, MID
114-023	SOLENOID VALVE, PIVOT, CARR IN/OUT
114-024	SOLENOID VALVE, BOTTOM
114-025	SOLENOID VALVE, TOP
200-002	POP RIVET
201-007	SEALS
201-066	BEARINGS, LINEAR
201-076	BEARING, SPINDLE TUBE
201-078	PILLOW BLOCK
201-079	SEAL, SPINDLE TUBE
203-040	AIR CYLINDER
203-045	AIR CYLINDER, CENTERING UP/DOWN
205-633	PLUG, HOLE
215-021	DOUPLING SHAFT 14"
99-00303	PULLEY ASS'Y
99-03804	EMI FILTER
99-05024-01	REFECTIVE SENSOR, LEFT
99-05024-02	REFECTIVE SENSOR, RIGHT
99-06025-03	INTERRUPTIVE SENSOR
99-06025-04	INTERRUPTIVE SENSOR
99-06062-01T	SPINDLE GUIDE HARNESS
99-06092-01T	TRACK HARNESS 86XX

MTI SPARE PARTS LIST FOR 86XX

PART NUMBER	DESCRIPTION
99-06625-01T	CARRIAGE HARNESS
99-06660-02T	SPINDLE DRIVE HARNESS
99-10290-01	VACUUM DELAY BOARD ASS'Y
99-80000-01	SINGLE SENSOR PCB
99-80001-01	PCB, DUAL SENSOR
99-80089A2-03	DUAL REFLECTIVE SENSOR/SPEED PCB
99-80089A3-02	DUAL INTER. SENSOR/SPEED PCB
99-80146-01T	VACUUM DELAY BOARD ASS'Y
99-80158-01	PCB, SINGLE SENSOR, ENCODER
99-AIO-035	KIT, SMC VACUUM SWITCH ASS'Y, SPIN MOD
99-AIO-106	O-RING BELT KIT

COATER MODULE

PART NUMBER	DESCRIPTION
112-041	STEPPER MOTOR FOR MOVING ARM
16981-01	TOP EBR NOZZLE FOR TEMP. CONTROL
17447-01M	TOP EBR NOZZLE, STANDARD
201-143	BEARING, ROTARY
202-158	TIMING BELT FOR MOVING ARM
203-008	AIR CYLINDER, SPINDLE UP/DOWN
203-072	CYLINDER FOR PIVOTING ARM
213-050T	VALVE, FINE METERING, 1/4" TUBE, EBR
213-131	FURON VALVE
213-139	TOP EBR 3-WAY VALVE
215-153	SHAFT, MOVING ARM
220-002	TIMING BELT PULLEY, MOTORSIDE
220-028	TIMING BELT PULLEY, ADJUSTSIDE
99-06082-01	HARNESS ASS'Y, MOVING & PIVOTING
99-17216-01	PIVOTING DISPENSE HARNESS
99-AIO-017	SPINDLE REBUILD KIT, 8626
AIO-0051	3-WAY SOLENOID, TOP EBR, AIR
AIO-0327	QUICK CONNECTER, FEMALE, KR, 1/4" OD
AIO-0328	QUICK CONNECTER, MALE, KR, 1/8" OD
AIO-0904	FLOWMETER FOR CCR
AIO-1426	FLOWMETER FOR TOP, BOTTOM EBR
AIO-1435	TOP EBT NOZZLE BRACKET, UPGRADE
AIO-1436	TOP EBR NOZZLE, UPGRADE

MTI SPARE PARTS LIST FOR 86XX

DEVELOPER (FIXED)

PART NUMBER	DESCRIPTION
03104	CAP, SPRAY NOZZLE
03105	STREAM NOZZLE
03106	CAP, STREAM NOZZLE
06854-01	NOZZLE SUPPORT, 8632, 8832 FIXED
203-005	CYLINDER, 8632 SPINDLE UP/DOWN
203-047	CYLINDER, SHIELD UP/DOWN
207-011	NOZZLE, SPRAY, SS11001
207-012	NOZZLE, SPRAY, SS800050
207-014	GASKET, NYLON, FOR SPRAY NOZZLE
99-00802	SHIELD UP/DOWN SENSOR ASS'Y
99-06062-01T	SPINDLE GUIDE PLATE HARNESS
99-AIO-018	SPINDLE REBUILT KIT
AIO-0027	FLOWMETER FOR CTD CART
AIO-0980	3-WAY TEFLON VALVE, PARKER, DI RETURN
AIO-1096	STREAM NOZZLE (DUAL)

DEVELOPER (MOVING DISPENSE)

PART NUMBER	DESCRIPTION
109-125	COVER SWITCH
112-041	STEPPER MOTOR
112-066	LOW SPEED MOTOR
112-067	HI-SPEED MOTOR
201-064	BEARING, BALL BUSHING LINEAR
201-085	SEAL, LINEAR BEARING 1/4" SHAFT
202-158	TIMING BELT
206-032	STREAM NOZZLE FOR MD
207-024	SPRAY NOZZLE, 1/8"NPT
220-002	PULLEY, TIMING BELT, MOTOR SIDE
220-028	PULLEY, TIMING BELT, ADJUST SIDE
99-14394-01T	SPINDLE DRIVE HARNESS ASS'Y
99-14416-01	ELEC. CLUTCH COUPLING ASS'Y
99-14430-01	MOVING DISPENSE HARNESS ASS'Y, 86,88/32
99-AIO-017	SPINDLE REBUILT KIT
AIO-1001	CYLINDER SPINDLE UP/DOWN 8632CTD-MD
AIO-1117	ELBOW FITTING FOR TOP RINSE NOZZLE
AIO-1260	GASKET FOR TOP RINSE NOZZLE

MTI SPARE PARTS LIST FOR 86XX

HOT PLATE MODULE

PART NUMBER	DESCRIPTION
04083M	THREAD STUD
04088	INSULATOR, CERAMIC
109-014	VACUUM SWITCH
109-093	SWITCH, OVERTEMP., LOW TEMP.
109-095	SWITCH, OVERTEMP., HI TEMP.
112-038	MOTOR, PULLEY FOR CARRIAGE, 10:1 RATIO
114-002	SOLENOID VALVE
114-006	SOLENOID, VACUUM
11969-01	TUBE, VACUUM FLARED
121-039	PROBE, T.C, J TYPE
121-039S	TEMPERATURE PROBE, RTD
121-042-01	HEATER, 115V, 450W, COIL
121-042-02	HEATER, 230V, 350W, COIL
121-044-01	HEATER, 115V, 750W, COIL
121-044-02	HEATER, 230V, 650W, COIL
121-095-01	HEATER, 115V, 750W, CAST IN
121-095-02	HEATER, 230V, 750W, CAST IN
121-095-03	HEATER, 115V, 400W, CAST IN
121-095-04	HEATER, 230V, 400W, CAST IN
201-007	SEAL, BUSHING BALL
201-066	BUSHING, BALL
222-001	CABLE, 16" HPO CARRIAGE
99-00303	PULLEY ASS'Y
99-03804	EMI FILTER
99-04006-02T	CARRIAGE HARNESS
99-04013-02	STEPPER MOTOR ASS'Y
99-04014-02T	WAFER CARRIER SENSOR HARNESS
99-05024-01	WAFER SENSOR ASS'Y, REFLECTIVE, LEFT
99-05024-02	WAFER SENSOR ASS'Y, REFLECTIVE, RIGHT
99-06025-03	WAFER SENSOR ASS'Y, INTERRUPTIVE, LEFT
99-06025-04	WAFER SENSOR ASS'Y, INTERRUPTIVE, RIGHT
99-80000-01	SINGLE SENSOR PCB
99-80082	HEATER/CONTROLLER INTER PCB
99-80089A2-02	DUAL INTER.SENSOR/SPEED PCB
99-80089A2-03	DUAL REFLECTIVE SENSOR/SPEED PCB
99-AIO-036	SMC VACUUM SWITCH ASS'Y
99-AIO-102	O-RING BELT KIT
AIO-0070	PIN, 3-PIN HPO
AIO-0988	HPO BLOCK

MTI SPARE PARTS LIST FOR 86XX

CHILL PLATE MODULE

PART NUMBER	DESCRIPTION
06010B	CHILL PLATE, FOR BANNER SENSOR
06024	FITTING 1/4" TUBE, CHILL WATER IN/OUT
109-014	VACUUM SWITCH
112-038	MOTOR, 10:1, 24VDC
114-006	SOLENOID, VACUUM
202-132	O-RING BELT
205-229-195	SCREW, NYLON
206-002	ADAPTER FOR VACUUM
210-015	SEAL, O-RING
99-06004T	CHILL PLATE HARNESS ASS'Y
99-15136-01	REFLECTIVE SENSOR ASS'Y
99-15136-02	BANNER SENSOR ASS'Y
99-80000-01	SINGLE SENSOR PCB
99-80089A-01	CP CONTROL PCB, REFLECTIVE SENSOR
99-80089A-01M	CP CONTROL PCB, BANNER SENSOR
99-AIO-037	SMC VACUUM SWITCH ASS'Y
99-AIO-104	O-RING KIT
AIO-0111	FITTING SUPPURT FOR WATER LINE, 1/4" TUBE

VAPOR PRIME MODULE

PART NUMBER	DESCRIPTION
08130-01	TUBE, VACUUM BLOCK
09089-01	WIRE, SST
112-038	CONVEYOR MOTOR
114-001	VALVE, SKINNER
114-002	VALVE, 4-WAY, 24VOLT
114-006	SOLENOID, VACUUM
114-012	VALVE, 2-WAY, SOLENOID
121-039S	TEMPERATURE PROBE
121-044-02	COIL ELEMENT
203-040	AIR CYLINDER
209-019	VACUUM REGULATOR
209-088	FLOWMETER, AIR(0-20)
210-027	SEAL, METAL (E-TYPE)
99-00303	PUELLY ASS'Y
99-03804	EMI FILTER
99-04006-02	CARRIAGE HARNESS
99-06025-03	INTERRUPTIVE SENSOR
99-06025-04	INTERRUPTIVE SENSOR
99-10627-01	5" HPO BLOCK
99-80082	HEATER/CONTROLLER INTER PCB
99-80089A2-02	DUAL INTER/SPEED CONTROL
99-80102A	VAPOR PRIME INTERLOCK PBC
99-AIO-111	O-RING BELT KIT
99-AIO-132	CANISTER ASS'Y FOR VP (KR), 1.5G
AIO-0088	FLOAT SWITCH, SST
AIO-0316	O-RING, SILICON
AIO-1033	FLOWMETER, HMDS

MTI SPARE PARTS LIST FOR 86XX

CARDCAGE ASSEMBLY

PART NUMBER	DESCRIPTION
06871-01	OVERLAY, 8626PC/8636HPO
06871-03	OVERLAY, 8620SSC
06871-04	OVERLAY, 8632CTD/8636HPO
06871-06	OVERLAY, 8628/8636HPO
06871-07	OVERLAY, 8642/8636HPO
06871-09	OVERLAY, 8632CTD-DD/8636HPO
09724-01	OVERLAY, 8638
09724-03	OVERLAY, 8636
103-11033	HS DRIVE TRANSISTOR
103-3715	HS BRAKE TRANSISTOR
103-6051	2N6051, LOW SPEED DRIVE, 8820SWEEP
109-080	KEY LOCK SWITCH
109-088	SWITCH, LIGHT BUTTON
111-016	FUSE, 3A, SLOW BLOW
111-018	FUSE, 1A, SLOW BLOW
111-023	FUSE, 1/8A PICO FUSE
111-025	FUSE, 5A (SLOW BLOW)
121-007	TRANSISTOR, UNSULTOR, SILPAD
124-005	VR1, 5 VOLT REGULATOR
13544-01	OVERLAY, 8640
205-137	WASHER, TEFLON
99-01989-02	COMMUNICATION CABLE
99-01993-01	CONTROL CABLE INTERCONNECT
99-15649-01	PCB INTERCONNECT HARNESS
99-80074	DEY BOARD PCB
99-80076B	PCB CONNECTOR INTERFACE BOARD
99-80092-02	TRANSISTOR BOARD ASS'Y
99-80106A	HCIU HARNESS
99-80122C	PCB I/O BOARD ASS'Y
99-AIO-901	PCB CPU BOARD ASS'Y
AIO-1073	OVERLAY, 8632CTD-MD/8636HPO
AIO-99-001	MOTHER & INTERFACE PCB ASS'Y

POWER SUPPLY ASSEMBLY

PART NUMBER	DESCRIPTION
111-003	FUSE, 5A
111-008	FUSE, 3A
111-010	FUSE, 10A
111-012	FUSE, 0.5A

MTI SPARE PARTS LIST FOR 88XX

INDEXER MODULE

PART NUMBER	DESCRIPTION
100-032	CAPACITIVE SENSOR
109-144	CASSETTE SENSOR
112-077	GEAR MOTOR, 24VDC, 65.5:1
16662-01	LEAD SCREW & NUT
201-003	BUSHING, BALL 1/2"
201-004	SEAL, BALL BUSHING
202-278	BELT, GEARED PULLEY
99-16310-03T	INDEXER HARNESS
99-80039D	INDEXER INTERFACE PCB, ANY SENSOR OK
99-80066B	PCB, QUAD SENSOR
AIO-0032	BANNER SENSOR

SPINDLE MODULE

PART NUMBER	DESCRIPTION
01091	VACUUM BOWL
109-014	VACUUM SWITCH
109-115	COVER SWITCH
112-005	HI-SPEED MOTOR
114-006	VACUUM SOLENOID
114-007	LIQUID SOLENOID (KR)
114-020	SOLENOID, SPINDLE MIDDLE
114-023	SOLENOID, CENTERING PAD/ARC, CCR, PIVOTING
114-024	SOLENOID, SPINDLE BOTTOM
114-025	SOLENOID, SPINDLE TOP
201-076S	BEARING, SPINDLE TUBE
201-078	PILLOW BLOCK, SPINDLE UP/DOWN
201-079	SEAL, SPINDLE TUBE
203-065	CYLINDER FOR CENTERING IN/OUT
205-252	BUTTON BUMPER
215-021	COUPLING
200-022	CAP RUBBER
99-06660-02T	SPINDLE DRIVE HARNESS
99-16079-01	COVER SWITCH HARNESS
99-16128-01	HARNESS, SUPPORTING PIN TEFLON
99-80000-01	SINGLE SENSOR PCB
99-80146-01	VACUUM DELAY BOARD ASS'Y
99-80158-01	SINGLE SENSOR PCB, ENCODER
99-AIO-035	SMC VACUUM SWITCH ASS'Y KIT

MTI SPARE PARTS LIST FOR 88XX

COATER MODULE

PART NUMBER	DESCRIPTION
112-041	STEPPER MOTOR, MOVING DISP. ARM
16981-01	TOP EBR NOZZLE, TEMP. CONTROL
17447-01M	TOP EBR NOZZLE, STANDARD
17458-01B	DRAIN ADAPTER
201-007	SEAL, BUSHING BALL
201-066	BUSHING BALL, LINEAR
201-143	BEARING, LINEAR, ROTARY
202-254	TIMING BELT FOR MOVING ARM
203-062	CYLINDER, AIR, SPINDLE UP/DOWN, 8826
203-072	CYLINDER, PIVOTING UP/DOWN
206-666	ELBOW, TEFLON FOR TOP EBR
213-050T	VALVE, FINE METERING 1/4" TUBE, EBR
213-131	FURON VALVE
213-139	TOP EBR 3-WAY VALVE
215-153	SHAFT, MOVING DISP. ARM
220-002	PULLEY, TIMING BELT, MOTOR SIDE
220-028	PULLEY, TIMING BELT, ADJUST SIDE
99-06082-01	HARNESS, MOVING & PIVOTING DISP. ARM
99-16085-01T	SPINDLE GUIDE PLATE HARNESS, 8826
99-17216-01	HARNESS, PIVOTING DISP. SENSOR
99-AIO-013	SPINDLE REBUILT KIT, 8826
AIO-0051	3-WAY SOLENOID, TOP EBR, AIR
AIO-0327	QUICK CON., FEMALE, 1/4" OD (KR)
AIO-0328	QUICK CON., MALE, 1/8" OD (KR)
AIO-0904	FLOWMETER FOR CCR
AIO-1426	FLOWMETER FOR EBR, TOP EBR
AIO-1435	TOP EBR NOZZLE BRACKET
AIO-1436	TOP EBR NOZZLE, UPGRADE

MTI SPARE PARTS LIST FOR 88XX

DEVELOPER (FIXED)

PART NUMBER	DESCRIPTION
03104	CAP, SPRAY NOZZLE
03105	STREAM NOZZLE (SINGLE)
03106	CAP, STREAM NOZZLE
03102	SPRAY NOZZLE
06854-01	NOZZLE SUPPORT
203-064	CYLINDER, SHIELD UP/DOWN
203-067	CYLINDER, SPINDLE UP/DOWN, 8832 FIXED
207-011	SPRAY NOZZLE, SS11001
207-012	SPRAY NOZZLE, SS800050
207-013	CAP, UNJET, SS
207-014	GASKET, NYLON, SPRAY NOZZLE
99-00802	SHIELD UP/DOWN SENSOR HARNESS
99-16359-02T	HARNESS, SPINDLE GUIDE PLATE, 8832 FIXED
99-AIO-007	SPINDLE REBUILT KIT, 8832 FIXED
AIO-1096	STREAM NOZZLE (DUAL)

DEVELOPER (MOVING DISPENSE)

PART NUMBER	DESCRIPTION
112-041	STEPPER MOTOR
112-066	MOTOR, LOW SPEED, 24VDC 65.5:1
112-067	HI-SPEED MOTOR
201-064	BEARING, BALL BUSHING LINEAR
201-085	SEAL, LINEAR BEARING 1/4" SHAFT
201-098	BEARING, FLANGED
202-211	TIMING BELT
202-262	PULLYE, TIMING BELT
203-074	CYLINDER, 8832MD SPINDLE UP/DOWN
206-032	STREAM NOZZLE FOR MD
207-024	SPRAY NOZZLE, 1/8"NPT, MOVING DISP.
220-033	PULLEY, TIMING BELT W/STEPPER MOTOR
99-14394-01	SPINDLE HARNESS FOR HI-LOW + ELEC. CLUTCH
99-14416-01	ELEC. CLUTCH COUPLING ASS'Y
99-14430-01	MOVING DISP. HARNESS ASS'Y 8832MD
99-80000-01	SINGLE SENSOR PCB
99-80158-01	SINGLE SENSOR PCB, ENCODER
99-AIO-008	SPINDLE REBUILD KIT
AIO-1117	ELBOW FITTING FOR TOP RINSE LINE
AIO-1260	GASKET FOR TOP RINSE NOZZLE

MTI SPARE PARTS LIST FOR 88XX

CHILL PLATE MODULE

PART NUMBER	DESCRIPTION
109-014	VACUUM SWITCH
114-002	4-WAY VALVE, 41E1-24DC
114-006	VACUUM SOLENOID
16185-01	CHILL PLATE
16188-01	PIN, WAFER CARRIER
201-001	ADAPTOR, 1/8", VACUUM
203-064	AIR CYLINDER
206-102	MALE CONNECTOR, CHILL WATER IN/OUT
99-16106-01	SENSOR, CYLINDER UP/DOWN
99-AIO-037	SMC VACUUM SWITCH ASS'Y

HOT PLATE MODULE

PART NUMBER	DESCRIPTION
04088	CERAMIC INSULATOR
109-014	VACUUM SWITCH
109-093	SWITCH, OVER TEMP, LOW TEMP
109-095	SWITCH, OVER TEMP, HIGH TEMP
112-053	STEPPER MOTOR
114-006	VACUUM SOLENOID
11969-01	TUBE, VACUUM FLARED
11970-01	SHIM, SST
121-039	TEMP PROBE TC ASS'Y
121-039S	TEMP PROBE RTD ASS'Y
121-042-01	HEATER, LOW TEMP, 115V, 450W, COIL
121-044-01	HEATER, HIGH TEMP, 115V, 750W, COIL
121-095-01	HEATER, HIGH TEMP, 115V, 750W, CASTING
121-095-02	HEATER, HIGH TEMP, 230V, 750W, CASTING
121-095-03	HEATER, LOW TEMP, 115V, 400W, CASTING
121-095-04	HEATER, LOW TEMP, 230V, 400W, CASTING
16194-01	LEAD SCREW
16195-01	COUPLING
16217-01	PIN, 3-PIN HPO
16246-01	NUT FOR COVER
201-007	SEAL, BUSHING BALL
201-066	BUSHING, BALL
205-190	RETAINING RING
216-067	CLAMP
99-16098-01	STEPPER MOTOR ASS'Y
99-16099-01	WAFER CARRIER TOP SENSOR HARNESS
99-80000-01	SINGLE SENSOR PBC
99-80082	HEATER/CONTROLLER INTER PCB
99-AIO-036	SMC VACUUM SWITCH ASS'Y
AIO-0146	WASHER, TEFLON
AIO-0988	BLOCK, 3-PIN HPO, 3-6"

MTI SPARE PARTS LIST FOR 88XX

VAPOR PRIME

PART NUMBER	DESCRIPTION
109-014	VACUUM SWITCH
109-108	COVER SWITCH
112-075	STEPPER MOTOR
114-001	SKINNER VALVE
114-002	VALVE, SOLENOID 4-WAY 41E1-24VDC
114-006	VACUUM SOLENOID
114-007	LIQUID SOLENOID (KR)
121-126	RESIST THERMO PROBE
209-008	BRACKET, REGULATOR
209-028	GAUGE 1.5 CANISTER 0-15PSI
209-033	REGULATOR
209-088	FLOWMETER 0-20SCFM
213-051	VALVE, SOLENOID, 24DC
99-16099-01	WAFER SENSOR TOP SENSOR HARNESS
99-16587-01T	STEPPER MOTOR HARNESS
99-16588-01T	LID UP SENSOR HARNESS
99-16594-01	8838 CAST HEATER ELEMENT ASS'Y
99-80000-01	SINGLE SENSOR ASS'Y
99-80102A	VP INTERLOCK PCB
99-AIO-038	SMC VACUUM SWITCH ASS'Y
99-AIO-132	1.5 GALLON CANISTER ASS'Y FOR VP (KR)
AIO-0088	FLOAT SWITCH SST
AIO-0844	FLOW SWITCH
AIO-1033	FLOWMETER, HMDS (VP)

TRANSFER ARM

PART NUMBER	DESCRIPTION
112-071	GEAR MOTOR, 24VDC, 65.5:1
114-038	VACUUM SOLENOID, 3-WAY
16163-01	LEAD SCREW & NUT, ROBOT ARM
16215-01	FOREARM 4.75" PICK-UP ARM
16290-01	FOREARM 3.00" PICK-UP ARM
16689-01	FOREARM 6.12" PICK-UP ARM
202-252	TIMING BELT 4.75"
202-253	O-RING, SEAL VACUUM
202-256	TIMING BELT 3.00"
202-279	TIMING BELT 6.12"
99-12586-01	EMI FILTER ASS'Y
99-16103-01T	88TRANSFORT ARM HARNESS
99-16104-02	PICK-UP ARM 6.12" ASS'Y
99-16104-03	PICK-UP ARM 3.00" ASS'Y
99-80000-01	SINGLE SENSOR PCB
99-80157-01	ARM PCB
99-80161-01	MOTHER PCB ASS'Y

MTI SPARE PARTS LIST FOR 88XX

CARDCAGE

PART NUMBER	DESCRIPTION
103-11033	MJ11033, HI-SPEED DRIVE, BRUSH8820
103-3715	2N3715, HI-SPEED DRIVE, BRUSH8820
103-6051	2N6051, LOW SPEED DRIVE, SWEEP 8820
109-080	KEYLOCK SWITCH
109-088	SWICH, LIGHTED PUSH BUTTON
111-016	FUSE, 3A(SLOW BLOW)
111-018	FUSE, 1A(SLOW BLOW)
111-023	FUSE, 1/8A, AXIAL LEAD PICO FUSE
111-025	FUSE, 5A(SLOW BLOW)
121-007	TRANSISTOR INSULATOR
124-005	LM323K, SYSTEM/SENSOR, VOLTAGE REGULATOR
18810-01	OVERLAY, 8820SSC/8836HPO
18810-03	OVERLAY, 8826PC/8836HPO
18810-04	OVERLAY, 8832CTD/8836HPO
18810-05	OVERLAY, 8840MHP
18810-06	OVERLAY, 8828PC/8836HPO
18810-07	OVERLAY, 8842SOG/8836HPO
18810-08	OVERLAY, 8842SOG
18810-09	OVERLAY, 8832CTD-DD8836HPO
18810-10	OVERLAY, 8832CTD-MD/8836HPO
18810-10S	OVERLAY, 8832MD-DD/8836HPO
18810-11	OVERLAY, 8838VP
18810-12	OVERLAY, 8836HPO
18810-13	OVERLAY, 8826PC
18810-14	OVERLAY, 8826SMC/8836HPO
205-098	DRAW CATCH, 2HOLE
99-01989-02	COMMUNICATION CABLE
99-16091-01	ARM-CARDCAGE INTERCONNECT HARNESS, 7PL
99-80073B	DISPLAY PCB ASS'Y
99-80074B	KEYBOARD PCB ASS'Y
99-80076B	PCB CONNECTOR INTERFACE BOARD
99-80092-01	TRANSISTOR BOARD ASS'Y
99-80105-01	MOTHER BOARD ASS'Y
99-80106A	HCIU HARNESS
99-80122C	TRACK I/O BOARD ASS'Y
99-AIO-901	CPU BOARD ASS'Y
AIO-0907	MOUNTING BRACKET
AIO-99-001	MOTHER & CONNECTOR INTERFACE PCB ASS'Y

POWER SUPPLY ASSEMBLY

PART NUMBER	DESCRIPTION
103-5884	24V REGULATOR
111-003	FUSE, 5A
111-008	FUSE, 3A
111-010	FUSE, 10A
111-012	FUSE, 0.5A